

File: 17G P.W.



NAVAL AIR STATION FORT WORTH JRB CARSWELL FIELD TEXAS

ADMINISTRATIVE RECORD COVER SHEET

AR File Number 489

Final Phase 2 RFI Work Plan for Oil/Water Separators Naval Air Station (NAS) Fort Worth Joint Reserve Base Carswell Air Force Base, Texas

Prepared for:

Air Force Center for Environmental Excellence
HSC/PKVCB
Headquarters Human Systems Center
Brooks Air Force Base, Texas 78235-5353

Prepared by:

IT Corporation 312 Directors Drive Knoxville, Tennessee 37923

October 1999

Naval Air Station Fort Worth Phase 2 RFI OWS Work Plan Revision: 0 October 1999 Page i of v

Table of Contents_

			Pa	ige
List of	f Tahl	ec		ii
List of	f Fim:	Tec		iii
		•		
1.0	1.1		t Objectives	
		_	t Investigation Methods	
20	1.2		and Existing Site Information	
2.0		_		
	2.1		escription	
	2.2		onmental Setting	
	2.3		istory and Operation	
		2.3.1	Ownership	
		2.3.2	Operation	
		2.3.3	Results of Previous Site Investigations	
3.0			stigation	
	3.1		Investigation Locations	
	3.2	OWS	Phase 2 RFI Surface Soil Investigation	. 12
	3.3	OWS:	Phase 2 RFI Subsurface Soil Investigation	. 13
	3.4	ows	Phase 2 RFI Groundwater Investigation	. 13
	3.5	Invest	igation-Derived Waste Management	. 15
4.0	Repo	orting	······································	. 17
5.0				
6.0	Proje	ect Man	nagement	. 19
7.0	Refe	rences		. 20
Table	s			
Figure	e s			

Naval Air Station Fort Worth Phase 2 RFI OWS Work Plan Revision: 0 October 1999 Page ii of v

List of Tables_

Table	Title	Follows Text
1	Oil/Water Separator RFI Locations	
2	Oil/Water Separator Phase 2 RFI Status Table With Recommended TNRCC Risk Reduction Program Action	
3	Analytical Soil Boring Samples	
4	Analytical Groundwater Samples	
5	Summary Table of all Soil Boring and Groundwater Samples	
6	Groundwater Field Sampling Test and Method Table	

Follows Text

Naval Air Station Fort Worth Phase 2 RFI OWS Work Plan Revision: 0 October 1999 Page iii of v

List of Figures_____

Figure	Title
1	Site Location Map
2	OWS Location Map
3	Building 1015 Soil Boring and Groundwater Monitoring Locations
4	Building 1027 Soil Boring and Groundwater Monitoring Locations
5	Building 1060 Soil Boring and Groundwater Monitoring Locations
6	Building 1064 Soil Boring and Groundwater Monitoring Locations
7	Building 1101 Soil Boring and Groundwater Monitoring Locations
8	Building 1145 Soil Boring and Groundwater Monitoring Locations
9	Building 1190 Soil Boring and Groundwater Monitoring Locations
10	Building 1191 Soil Boring and Groundwater Monitoring Locations
11	Building 1194 Soil Boring and Groundwater Monitoring Locations
12	Building 1320 Soil Boring and Groundwater Monitoring Locations
13	Building 1414 Soil Boring and Groundwater Monitoring Locations
14	Building 1423 Soil Boring and Groundwater Monitoring Locations
15	Building 1602 Soil Boring and Groundwater Monitoring Locations
16	Building 1628 Soil Boring and Groundwater Monitoring Locations
17	Building 1643 Soil Boring and Groundwater Monitoring Locations
18	Building 1655 Soil Boring and Groundwater Monitoring Locations
19	Building 1656 Soil Boring and Groundwater Monitoring Locations
20	Building 3358 Soil Boring and Groundwater Monitoring Locations
21	Building 4146 Soil Boring and Groundwater Monitoring Locations
22	Building 4160 Soil Boring and Groundwater Monitoring Locations
23	Building 4210 Soil Boring and Groundwater Monitoring Locations
24	OWS Phase 2 RFI Addendum Report Outline
25	Project Schedule - OWS Phase 2 Investigation
26	Project Organization

Naval Air Station Fort Worth Phase 2 RFI OWS Work Plan

Revision: 0 October 1999 Page iv of v

List of Acronyms

AFB Air Force Base

AFCEE Air Force Center for Environmental Excellence

AOC area(s) of concern

EPA U.S. Environmental Protection Agency

FSP field sampling plan HGL Hydrogeologic Inc.

IRP Installation Restoration Program

IT IT Corporation

Law Environmental, Inc.

LNAPL light nonaqueous-phase liquid

MSC media-specific concentration

NAS Naval Air Station Fort Worth

OWS oil/water separator

PID photoionization detector

PQL practical quantification limit

QA/QC quality assurance/quality control
QAPP quality assurance project plan

RCRA Resource Conservation and Recovery Act

RFI RCRA Facility Investigation

RRS Risk Reduction Standard

SAP sampling and analysis

SPLP Synthetic Precipitation Leaching Procedure

SVOC semivolatile organic compound
SWMU Solid Waste Management Unit

TCA trichloroethane

TCE trichloroethene
TNRCC Texas Natural Resource Conservation Commission

UTL upper tolerance level

VOC volatile organic compound

Naval Air Station Fort Worth Phase 2 RF1 OWS Work Plan Revision: 0 October 1999 Page 1 of 21

1.0 Introduction

IT Corporation (IT) has been contracted by the Air Force Center for Environmental Excellence (AFCEE) to prepare a Phase 2 Resource Conservation and Recovery Act (RCRA) Facility Investigation (RFI)/addendum report to evaluate existing information, obtain additional data as needed, and prepare a Phase 2 RFI addendum work plan for 21 oil/water separator (OWS) locations at the Naval Air Station (NAS) Fort Worth Joint Reserve Base, Carswell Field, Texas. IT is performing this work under Contract F41624-94-D-8047, Delivery Order 39.

This Phase 2 RFI work plan is to provide: objectives for the additional investigation of the OWSs at NAS Fort Worth, the plan of investigation for additional field investigation of OWSs, the methods for reporting the regulatory status of each OWS in accordance with Texas Natural Resource and Conservation Commission (TNRCC) Risk Reduction Standards (RRS), and requests for no further action status and closure of selected OWSs connected to the Sanitary Sewer System (Solid Waste Management Unit [SWMU] 66). Results of work previously performed on the OWSs are provided in the draft OWS RFI addendum report (IT, 1998a). This OWS Phase 2 RFI work plan includes by reference the findings provided in the draft Sanitary Sewer System RFI report (IT, 1997a).

Additional investigation of the OWSs will comply with the requirements specified in the work plan and Quality Program Plan for the Sanitary Sewer System investigation (IT, 1997b,c,d). The Quality Program Plan includes a health and safety plan and a sampling and analysis plan (SAP). The health and safety plan is a project-specific and site-specific plan. The SAP consists of two volumes: the field sampling plan (FSP) and the quality assurance project plan (QAPP). The FSP describes the methods to be used in the collection analysis of additional site data samples. The QAPP documents the data quality objectives and the quality assurance/quality control (QA/QC) procedures to be used in the performance of field and laboratory work.

This document amends the NAS Fort Worth Sanitary Sewer System RFI work plan (IT, 1997b) and FSP (IT, 1997d) and presents the proposed sampling locations and sampling rationale. The sampling locations and analytical methods will be reviewed by the TNRCC before field work begins. This document will provide the OWS locations to be further investigated, define the

Naval Air Station Fort Worth Phase 2 RFI OWS Work Plan Revision: 0 October 1999 Page 2 of 21

analytical samples to be collected, provide reference for sample collection methods, explain the rationale for the sample collection, and provide sufficient information to serve as the Phase 2 FSP. The work plan will be based on the modification of the existing NAS Fort Worth Sanitary Sewer System RFI work plan (IT, 1997b) and FSP (IT, 1997d) and will include:

- · Locations for delineation and rationale for sampling
- · Draft final OWS RFI report outline
- Provisions for Synthetic Precipitation Leaching Procedures (SPLP) sample analysis
 to allow RRS 2 closure of locations where soils exceed background upper tolerance
 level (UTL) for inorganic constituents and practical quantification limit (PQL) for
 organic constituents

The recently promulgated TNRCC Risk Reduction Program Rule will be compared to the RRSs to allow an evaluation of the most effective remedial alternatives for OWS. The Air Force will be presented recommendations on which program will be most effective.

1.1 Project Objectives

After completion of the Sanitary Sewer System RFI report, TNRCC comments indicated additional delineation of contaminants detected would be required for completion of the RFI. Compliance with TNRCC RRSs for completion of the OWS RFIs will require additional lateral delineation of contaminants exceeding background UTLs or analytical methods PQLs. The work plan does not include corrective measures, such as detailed contaminant delineation sampling or legal surveys of the contaminated OWS site boundaries and deed restrictions, to provide closure of the site.

The objectives of this investigation are:

- Obtain additional data necessary to adequately assess the extent of OWS-related soil and groundwater contamination for constituents detected above TNRCC RRS 2.
- Consolidate additional OWS data in a Phase 2 RFI addendum report compliant with TNRCC regulations and procedures.
- Prepare an interim corrective measures work plan for the OWSs identified, evaluate candidate technologies, and recommend appropriate remediation, if warranted.

Naval Air Station Fort Worth Phase 2 RFI OWS Work Plan Revision: 0 October 1999 Page 3 of 21

- Prepare documents for "no further action" for the OWSs where contaminants were determined not to exceed TNRCC RRS 1.
- Prepare documents for submittal of closure in place where contaminants exceeded TNRCC RRS 1 but were determined not to pose a threat to groundwater by leaching from soils and meet closure criteria under RRS 2.
- Allow for property transfer of parcels containing the OWSs.

1.2 Project Investigation Methods

Evaluation of the analytical data from the draft Sanitary Sewer System RFI report indicates sample locations can be categorized as:

- · Locations requiring further delineation
- Locations requiring sample confirmation due to detections less than one order of magnitude above RRS 1
- Locations not requiring additional delineation due to influences from comingled plumes or proven anthropogenic contaminants
- Locations not requiring additional delineation due to organic analytes not exceeding analytical method PQL or inorganic analytes not exceeding background UTLs.

The estimated number of soil and groundwater samples is based on the locations that had constituents exceeding background UTLs or PQLs. These investigation locations are divided into confirmation and delineation. These will provide both confirmation of sampling results and additional delineation of the lateral extent of contamination. Samples collected in already delineated areas (SWMUs or previously documented known spill sites) were not used in selection determination.

The basis for selection for removal of the sample locations from the Sanitary Sewer System RFI data is as follows:

- Remove organic analytes not exceeding Method PQL.
- · Remove inorganic analytes not exceeding background UTLs.

Naval Air Station Fort Worth Phase 2 RFI OWS Work Plan Revision: 0 October 1999 Page 4 of 21

- Remove groundwater sample locations from spill sites and the Air Force Plant 4 trichloroethene (TCE) groundwater plume.
- Removal of sample locations that have contaminants suspected of anthropogenic source (polynuclear aromatic hydrocarbons from asphalt), and detections suspected to be caused by laboratory contamination, single detections of uncommon constituents that do not have an identified local industrial source.

Naval Air Station Fort Worth Phase 2 RFI OWS Work Plan Revision: 0 October 1999 Page 5 of 21

2.0 Background and Existing Site Information

2.1 Site Description

NAS Fort Worth is located in north-central Texas in Tarrant County, 8 miles west of downtown Fort Worth (see Figure 1). A description of NAS Fort Worth and the surrounding area is provided in the NAS Fort Worth Sanitary Sewer System work plan (IT, 1997b). The OWSs are located throughout the industrialized areas of NAS Fort Worth (see Figure 2).

2.2 Environmental Setting

Description of the environmental setting at NAS Fort Worth is fully described in the Sanitary Sewer System RFI work plan (IT, 1997b).

2.3 Site History and Operations

2.3.1 Ownership

Description of the site history and ownership at NAS Fort Worth is fully described in the Sanitary Sewer System RFI work plan (IT, 1997b).

2.3.2 Operation

Before the construction of the initial airfield facilities in 1942, the area now occupied by NAS Fort Worth was pasture land and woods. The majority of the NAS Fort Worth property was acquired in the 1940s, with most of the property acquired from the city of Fort Worth in 1941. Additional property, including most of the south Base, the hospital area, and the Off-Site Weapons Storage Area, was acquired during the 1950s. Kings Branch and the south Base residential areas were acquired in 1960. Several miscellaneous additional properties totaling less than 10 acres have been acquired since 1970 (Jacobs Engineering, 1995a,b).

From 1942 until 1994, the former Carswell Air Force Base (AFB) and its Army predecessors served as a bomber and bomber training base. Carswell AFB was realigned as NAS Fort Worth in 1994. Wastes have been generated and disposed of at the facility since the beginning of industrial operations in 1942. The major industrial operations at NAS Fort Worth included: maintenance of jet engines, aerospace ground equipment, fuel systems, weapons systems, and

Naval Air Station Fort Worth Phase 2 RFI OWS Work Plan Revision: 0 October 1999 Page 6 of 21

hydraulic systems; maintenance of general and special purpose vehicles; aircraft corrosion control; and nondestructive inspection activities (Jacobs Engineering, 1995a,b).

"Waste oils" generally refers to lubricating fluids, such as crankcase oils and synthetic turbine oils. Hydraulic fluids have also been included in this category. "Recoverable fuels" refers to fuel drained from aircraft tanks and vehicles, such as jet propulsion fuel grade 4 and motor gasoline. "Spent solvents and cleaners" refers to liquid used for degreasing and general cleaning of aircraft, aircraft systems, electronic components, and vehicles. This category includes PD-680 and various chlorinated organic compounds, such as carbon tetrachloride, TCE, and 1,1,1trichloroethane (TCA).

Specific types of solvents used by the Air Force have changed over the years. In the 1950s, carbon tetrachloride was in common use. Its use was replaced by TCE about 1960. Since then, TCE and 1,1,1-TCA have been commonly used; however, TCE usage has decreased in favor of 1,1,1-TCA. Today, PD-680 Type II, 1,1,1-TCA, and TCE are used.

Waste paint solvents or thinners and strippers are generated by corrosion control activities. Typical thinners include isobutyl acetate, toluene, methyl ethyl ketone, isopropanol, naphtha, and xylene. Paint strippers generally contain such compounds as methylene chloride, toluene, ammonium hydroxide, and phenolics (CH2M Hill, 1996).

All of these operations generated waste materials, primarily oils, recoverable fuels, spent solvents, and cleaners. Most waste oils, recovered fuels, spent solvents and cleaners were either burned at fire training areas on the NAS Fort Worth, reused on NAS Fort Worth, or processed through the Defense Property Disposal Office. An undetermined amount of these materials were discharged through the OWSs to the Sanitary Sewer System at the NAS Fort Worth (Jacobs Engineering, 1995a,b).

2.3.3 Results of Previous Site Investigations

In 1984, the Installation Restoration Program (IRP) was initiated at NAS Fort Worth and began with a program records search conducted by CH2M Hill, Inc. Since 1984, Air Force IRP studies have been conducted by several contractors, and have focused on the identification and characterization of waste disposal areas and SWMUs identified in the installation's RCRA Part B permit.

Naval Air Station Fort Worth Phase 2 RFI OWS Work Plan Revision: 0 October 1999 Page 7 of 21

Several OWSs were designated as SWMUs in an RFI report by U.S. Environmental Protection Agency (EPA) (A.T. Kearney, 1989). Eight OWSs were designated as SWMUs and four were designated as areas of concern (AOC).

An investigation of 11 OWSs at NAS Fort Worth was performed by Law Environmental, Inc. (Law) to assess contamination and evaluate the condition and future use of the OWSs. The Law report indicated that two of the separators, located at Building 1015 (SWMU No. 47) and Building 1194 (SWMU No. 35), were connected to the Sanitary Sewer system. The discharge connections of the remaining OWSs investigated were not reported, but are assumed connected to the Sanitary Sewer System (Law, 1995).

Shallow and deep soil samples were collected by Law at the 11 units and analyzed for volatile organic compounds (VOC) by EPA Method SW8240 and RCRA metals (except mercury) by EPA Method SW6010. No analyses for semivolatile organic compounds (SVOC) were performed, but organic odors were detected during sampling activities. No groundwater samples were collected for the Law investigation. None of the soil samples analyzed contained volatile organics above TNRCC RRSs. Soils in the immediate area of each of the 11 OWSs, however, were contaminated with metals concentrations exceeding TNRCC RRSs (Law, 1995).

IT conducted an RFI on the Sanitary Sewer System (SWMU No. 66) in 1997. For the RFI, soil, groundwater, and geotechnical data were collected. Results of this investigation were published by IT in the draft Sanitary Sewer System RFI report in August 1997 (IT, 1997a). The Sanitary Sewer System RFI report indicated no unacceptable risk to human health or the environment from past management practices of the Sanitary Sewer System. The draft RFI reported the extent of some releases was not known.

During the Sanitary Sewer System RFI, IT collected additional soil, groundwater, and geotechnical data where OWS data gaps had been identified. These samples were collected at the OWSs to assess the nature of contamination at the OWSs and to determine potential impacts of past releases of industrial sewer discharges from the OWSs into the Sanitary Sewer System.

At the eight OWSs previously investigated by Law that were connected to the Sanitary Sewer System, IT collected soil samples and performed supplemental SVOCs and pesticides/

Naval Air Station Fort Worth Phase 2 RFI OWS Work Plan Revision: 0 October 1999 Page 8 of 21

polychlorinated biphenyls analysis, installed monitoring wells, and sampled groundwater for VOCs, SVOCs, and metals. At OWSs that were not previously investigated by Law, IT collected near surface and subsurface soils that were analyzed for VOCs, SVOCs, pesticides/polychlorinated biphenyls, and metals, and monitoring wells were installed for sampling groundwater for VOCs, SVOCs, and metals. Results of this investigation were published by IT in the draft Sanitary Sewer System RFI report in August 1997. The draft Sanitary Sewer System RFI report identified the Building 1145 and Building 3358 OWSs for additional investigation to determine the vertical and horizontal extent of contaminants in soil and groundwater at the two OWSs (IT, 1998b).

The OWS RFI addendum report (IT, 1998a) presented the combined investigation findings from the draft Sanitary Sewer System RFI report and additional investigation of 21 OWSs. As shown by Table 1-1 of that addendum report, 8 OWSs have been identified as SWMUs and four have been identified as AOC. Nine of the OWSs have not been designated as either a SWMU or AOC.

Additional investigation was conducted at the Building 1145 OWS (AOC No. 13), where light nonaqueous-phase liquid (LNAPL) was discovered on the groundwater during the 1997 RFI, and at Building 3358. Additional investigation was performed at the Building 3358 OWS to determine the horizontal extent of near-surface soil contamination, and the findings show the metals and organic contamination in surface soils is limited to one sample location. Investigation findings from the Building 1145 OWS show the LNAPL found on the water table in monitoring well WITCTA036 is limited in lateral extent to the vicinity of this location. Dissolved-phase groundwater contamination associated with the monitoring well WITCTA036 LNAPL is also restricted to a limited area surrounding this location. Surface and subsurface soil contamination is also limited in extent due to the removal of the leaking OWS in 1995; the excavated area was backfilled with clean fill.

In the OWS RFI addendum report (IT, 1998a), evaluation of the closure status of each of the 21 OWS units was made to TNRCC RRSs. All OWSs were recommended for either Standard I or Standard II closure. The TNRCC RRSs defined in 30 TAC 335 Subchapter S specify a consistent risk management policy to define the cleanup actions necessary to protect human health and the environment. The RRSs define the following three tiers of cleanup standards:

Naval Air Station Fort Worth Phase 2 RFI OWS Work Plan Revision: 0 October 1999 Page 9 of 21

- RRS 1 requires a cleanup to nondetectable levels or background levels unaffected by waste management activities for all contaminants. This level of a cleanup is commonly referred to as "clean closure." Deed certification on the property and post-closure care is not required under this standard.
- RRS 2 requires a cleanup to health-based levels such that any substantial threat to human health or the environment is reduced to acceptable levels. Deed certification on the property is required.
- RRS 3 requires a site-specific baseline risk assessment to define alternative cleanup levels based on health effects. Deed certification and post-closure care are required under this standard.

The OWS RFI addendum report (IT, 1998a) presented the TNRCC RRSs status of each OWS at NAS Fort Worth. Where the contaminant concentrations did not exceed background UTL, the OWS was recommended for Standard I closure. One OWS of the twenty-one investigated, the Building 1628 OWS, met this requirement. Where contaminant concentrations exceeded background UTLs only and not media-specific concentrations (MSC), the OWS was recommended for RRS 2, which requires deed certification. Seven of the OWSs met this requirement. For an OWS that has contaminants exceeding both UTLs and MSCs in either soil and/or groundwater, the OWS was recommended for RRS 2 closure. The report indicated that for most of the OWSs, one or two of the soil sample locations had metals, specifically arsenic and cadmium, that were approximately twice the concentration of the MSCs. It was recommended that additional sampling be performed at these locations to determine if the detections of metals are statistically significant and to allow preparation of corrective measures.

Based on TNRCC review of the OWS RFI addendum report, discussions were held between the Air Forcè and TNRCC to define the process for evaluating the existing data and selecting sites requiring additional investigation. Additional investigation is required for the OWSs exceeding RRS 2 levels. Criteria developed for determining the selection of locations requiring additional assessment of selected environmental media are as follows:

• Locations requiring resampling to confirm constituent detections less than one order of magnitude above RRS 1 background concentration UTL criteria

Naval Air Station Fort Worth Phase 2 RFI OWS Work Plan Revision: 0 October 1999 Page 10 of 21

- Locations requiring contaminant lateral delineation due to detections exceeding an order of magnitude above the background concentration UTL and the occurrence of the contaminant is consistent with past waste operations at the site
- Locations requiring analysis by the SPLP (EPA SW846 Method 1312) to determine if contaminants exceeding the RRS 2 criteria may leach from soil to groundwater.

Naval Air Station Fort Worth Phase 2 RFI OWS Work Plan Revision: 0 October 1999 Page 11 of 21

3.0 Plan of Investigation

This chapter of the work plan defines the scope of work to be performed during the additional investigation at the OWSs listed in Table 1. Activities associated with the collection of analytical data for site characterization at each site are addressed in this chapter. These investigation activities include collection of soil samples (surface/near-surface and subsurface), groundwater, and surface water.

The location of NAS Fort Worth is shown in Figure 1. The locations of the OWSs throughout the industrialized areas of the facility are shown in Figure 2.

3.1 OWS Investigation Locations

Varying methods will be used for collection at different media and allow contaminant delineation in the near-surface soil, subsurface soil, and groundwater. The data presented in Table 2 summarizes the contaminants at specific locations that exceeded TNRCC RRSs. Data presented in Table 2 show OWS sample locations where contaminants exceeded either the background concentration, the TNRCC RRSs, or the human health protective limits developed in the Sanitary Sewer System RFI risk assessment. Information presented in Table 2 was used to identify the data gaps that need to be closed to allow completion of the OWS RFI assessment under the TNRCC RRSs.

Table 3 shows soil sample locations and Table 4 shows groundwater sample locations requiring additional OWS contaminant delineation, which include:

- Twelve near-surface soil sample locations
- Sixteen subsurface soil sample locations
- Four installed monitoring wells and groundwater samples
- Nine monitoring well groundwater confirmation samples.

Table 5 shows the number of analyses required to delineate lateral contamination including:

Naval Air Station Fort Worth Phase 2 RFI OWS Work Plan Revision: 0 October 1999 Page 12 of 21

- Soils (45 specific metals, 17 SPLP for specific metals)
- Groundwater samples (4 VOCs, 21 metals)
- Three groundwater VOC analyses (3 existing monitoring wells)
- Eleven groundwater metals analyses (6 existing monitoring wells, 4 new monitoring wells).

These analyses do not include the number of field (10 percent field blanks and 1 daily equipment blank) and laboratory QA/QC samples (5 percent matrix spike/matrix spike duplicate).

3.2 OWS Phase 2 RFI Surface Soil Investigation

Soil samples will be collected to either delineate potential soil contamination or confirm low detections of contaminants. The near-surface soil samples will be discrete grab samples collected from 0 to 2 feet in depth. The near-surface soil samples will be collected at locations shown on Figures 3 through 23. The number of soil samples to be collected and parameters to be analyzed are shown in Table 3.

The sample tubes will be driven into the ground with a direct-push technology soil probe. All sampling equipment will be decontaminated before its use. Specific soil sample collections techniques are provided in the FSP (IT, 1997d).

Criteria for selection of near-surface soil sample locations are as follows:

- Locations requiring resampling to confirm constituent detections less than one order of magnitude above RRS 1 background concentration UTL criteria
- Locations requiring contaminant lateral delineation due to detections exceeding an
 order of magnitude above the background concentration UTL and the occurrence of
 the contaminant is consistent with past waste operations at the site
- Locations requiring analysis by the SPLP (EPA SW846 Method 1312) to determine
 if contaminants exceeding the RRS 2 criteria present a potential release of soil
 constituents by leaching from soil to groundwater.

Lab Methods. Near-surface soil samples will be submitted for analysis using EPA SW846 Method SW6010 RCRA metals, including mercury. Metals analysis will be performed to ensure

Naval Air Station Fort Worth Phase 2 RFI OWS Work Plan Revision: 0 October 1999 Page 13 of 21

the method reporting limit is lower than the constituent background UTL concentration. Analytical parameters and the number of samples to be collected are shown in Tables 3 and 5.

3.3 OWS Phase 2 RFI Subsurface Soil Investigation

Subsurface soil samples will be collected at several locations at the OWSs requiring additional investigation. The subsurface soil sampling locations are shown on Figures 3 through 23. The sample location and proposed analytical parameters selected for each soil sample are shown on Table 3.

The subsurface soil samples will be collected with direct-push technology soil probe methods as described in the previous section.

Criteria for the subsurface soil sampling locations follow the same criteria as those used for soil samples, as described in the previous section.

One subsurface soil sample will be collected at each soil boring. The subsurface soil sample collected at each soil boring will be collected from 2 feet above the groundwater elevation to the top of the water table. Field screening procedures will be used where visible contamination is observed or headspace soil field screening indicates the presence of organic contaminants. The project manager will be called to determine if an additional subsurface soil sample is required if unanticipated organic contamination is detected. Field screening procedures will follow those outlined in the Sanitary Sewer RFI FSP (IT, 1997c).

Lab Methods. Subsurface soil samples will be submitted for analysis using EPA SW846 Method SW6010 RCRA metals, including mercury. Metals analysis will be performed to ensure the method reporting limit is lower than the constituent background UTL concentration. Analytical parameters and the number of samples to be collected are shown in Tables 3 and 5.

3.4 OWS Phase 2 RFI Groundwater Investigation

Groundwater will be investigated at ten OWS locations for this phase of work. Groundwater samples will be collected to either confirm previous detections of constituents less than one order of magnitude above background concentration UTLs and PQLs, or delineate contaminants exceeding RRS 2 MSCs. Fourteen locations will be sampled by low flow methods to confirm

Naval Air Station Fort Worth Phase 2 RFI OWS Work Plan Revision: 0 October 1999

Page 14 of 21

the low concentration of constituents detected during the Sanitary Sewer System RFI (IT. 1998a). Eleven locations will be sampled to confirm low detections of specific inorganic constituents. One location will have three wells resampled to confirm chlorinated VOCs detected in wells installed during the first phase of the OWS RFI investigation. One location (monitoring well WITCTA031) will have the original monitoring well resampled to confirm the original detection of 51 micrograms per liter arsenic, which exceeded the maximum contaminant level (MCL). Four monitoring wells will be installed surrounding the monitoring well WITCTA031 to determine the extent of the dissolved arsenic plume.

Objectives of the groundwater sampling are as follows:

- Confirm the presence of groundwater constituents exceeding TNRCC RRS 1 background concentration UTL.
- Confirm the presence of groundwater constituents exceeding TNRCC RRS 2 MSCs and EPA MCLs.
- Define the lateral extent of the dissolved metal plumes.
- Characterize groundwater conditions at the sites.

Investigation Procedures. Proposed groundwater monitoring well locations for the Building 1191 SWMU will be determined in the field. Two wells will be installed west of Building 1191, which is upgradient of the two OWS. Two wells will be placed south of Building 1191 along the southern boundary fence to determine the extent of the arsenic detections. The monitoring wells will be installed to determine the lateral extent of the dissolved metals groundwater plume. The objective of the program will guide subsequent monitoring well placement if the original monitoring wells do not define the lateral extent of the groundwater plumes.

One monitoring well will be located upgradient of the OWS in an area determined by examination of the groundwater gradient. One monitoring well will be placed downgradient of the OWS but outside of the plume. Two monitoring wells will be installed laterally from the monitoring well WITCTA031 to define the extent of the dissolved metals plume. Monitoring wells will be built according to construction procedures outlined in the project SAP. Low flow sampling methods and the field measurement of groundwater parameters outlined in the Sanitary

Naval Air Station Fort Worth Phase 2 RFI OWS Work Plan Revision: 0 October 1999 Page 15 of 21

Sewer System FSP will be used to collect groundwater samples from the permanent monitoring wells (IT, 1997c).

Laboratory Methods. Groundwater confirmation samples from permanent monitoring wells will be collected and submitted for analysis using EPA SW846 Methods SW8260 VOA and SW6010 RCRA metals, including mercury. Analytical parameters for both temporary and permanent monitoring well groundwater samples are shown in Table 4. The total number of samples collected, including QC samples, are shown in Table 4. The total number of samples to be collected and the analytical program are shown on Table 5.

Groundwater field parameters will be measured during collection of samples from both temporary monitoring wells and permanent monitoring wells that have been installed. Parameters to be measured in the field include pH, temperature, conductivity, dissolved oxygen, turbidity, and redox potential. Field analysis parameters are shown on Table 6.

3.5 Investigation-Derived Waste Management

Wastes that may be generated during the RFI site investigation include: (1) purged groundwater, (2) decontamination water, (3) drill cuttings, (4) expendable protective clothing (e.g., Tyvek), and (5) general trash. Modifications to the planned waste management may be made if waste attributes change or field observations warrant a change. The general waste management approach is presented in this subsection; the detailed approach is included in the FSP (IT, 1997d).

All groundwater generated during monitoring well development and purging and decontamination water generated during decontamination process will be contained on-site (base) at the central storage location. All water will be stored in labeled, 55-gallon, U.S. Department of Transportation drums. The water will be tested for VOCs, diesel range organics, gasoline range organics, and metals and the analytical results reviewed to determine if the water requires treatment before disposal. If treatment is required, the water will be treated and tested prior to discharge to the sanitary sewer. The analytical results will be provided to NAS Fort Worth environmental authorities for review and approval before discharge to the NAS Fort Worth Sanitary Sewer System.

Naval Air Station Fort Worth Phase 2 RFI OWS Work Plan Revision: 0 October 1999 Page 16 of 21

Drill cuttings from soil probe and drilling activities will be contained in drums, which will be labeled and kept at the NAS Fort Worth designated storage location until analytical data are received. Contaminated soils will be disposed of at an appropriate licensed landfill, most likely as industrial, nonhazardous waste.

Waste disposal activity will be coordinated with NAS Fort Worth environmental authorities. Any hazardous waste disposal will be at a site selected by NAS Fort Worth environmental authorities, who will sign any transportation manifest as the "generator." All waste management practices will follow the guidelines established by the TNRCC.

Naval Air Station Fort Worth Phase 2 RFI OWS Work Plan Revision: 0 October 1999 Page 17 of 21

4.0 Reporting

After the available data have been evaluated, including field characterization data from the OWS RFI, a report will be prepared that compiles and evaluates the information. The primary objective of the OWS Phase 2 RFI addendum report will be to compile all existing data, evaluate the data by current TNRCC regulations, and present conclusions as to the need for remedial or other actions.

A preliminary outline of the report is shown in Figure 24. The outline follows the guidelines specified by TNRCC for a comprehensive site assessment report under the Risk Reduction Program.

5.0 Schedule

The project schedule is shown on Figure 25.

Naval Air Station Fort Worth Phase 2 RFI OWS Work Plan Revision: 0 October 1999 Page 19 of 21

6.0 Project Management

The objectives of this OWS Phase 2 RFI investigation are to:

- Complete OWS Phase 2 RFI addendum report tasks in accordance with this work
 plan, the Sanitary Sewer System RFI health and safety plan, and the Sanitary Sewer
 System RFI QAPP as scheduled and within the allotted budget.
- Communicate with project participants (Air Force Base Conversion Agency, AFCEE, TNRCC, EPA) the technical compliance, scheduled and actual program progress, and budgetary status of the project as appropriate.
- Complete and issue an OWS Phase 2 RFI addendum report.
- Submit to regulatory agencies recommendations for suggested remedial actions at OWS.

This task includes coordinating among other RFI project participants, as well as tracking schedules and budgets and preparing monthly status reports to AFCEE. Preparation of project information, forecasting, and updating of schedules and budgets will also be done under this task.

A more detailed description of project organization and responsibility is provided in Section 3.0 of the QAPP (IT, 1997c). The project organization is shown on Figure 26.

Naval Air Station Fort Worth Phase 2 RFI OWS Work Plan Revision: 0 October 1999 Page 20 of 21

7.0 References

CH2M Hill, 1996, HQ Air Force Center for Environmental Excellence, Interim Draft, Naval Air Station Fort Worth Joint Reserve Base, Base-Wide Quality Assurance Project Plan, August 1996.

IT Corporation (IT), 1998a, Air Force Center for Environmental Excellence, NAS Fort Worth Joint Reserve Base, Fort Worth, Texas, Draft Oil Water Separator RCRA Facility Investigation Addendum Report, July 1998.

IT Corporation (IT), 1998b, Air Force Center for Environmental Excellence, NAS Fort Worth Joint Reserve Base, Fort Worth, Texas, Draft Oil Water Separator RCRA Facility Investigation Work Plan, January 1998.

IT Corporation (IT), 1997a, Air Force Center for Environmental Excellence, NAS Fort Worth Joint Reserve Base, Fort Worth, Texas, Draft Sanitary Sewer System RCRA Facility Investigation Report, September 1997.

IT Corporation (IT), 1997b, Air Force Center for Environmental Excellence, NAS Fort Worth Joint Reserve Base, Fort Worth, Texas, Sanitary Sewer System RCRA Facility Investigation Work Plan, January 1997.

IT Corporation (IT), 1997c, Air Force Center for Environmental Excellence, NAS Fort Worth Joint Reserve Base, Fort Worth, Texas, Sanitary Sewer System RCRA Facility Investigation Quality Assurance Project Plan Addendum, January 1997.

IT Corporation (IT), 1997d, Air Force Center for Environmental Excellence, NAS Fort Worth Joint Reserve Base, Fort Worth, Texas, Sanitary Sewer System RCRA Facility Investigation Field Sampling Plan, January 1997.

Jacobs Engineering, 1995a, Air Force Center for Environmental Excellence, Naval Air Station Fort Worth Joint Reserve Base, Full-Service Environmental Remediation, Part 1, Quality Program Plan, January 1995.

Jacobs Engineering, 1995b, Air Force Center for Environmental Excellence, Naval Air Station Fort Worth Joint Reserve Base, Full-Service Environmental Remediation, Quality Program Plan, Part 2, Sampling and Analysis Plan, January 1995.

Kearney, A. T., 1989, RCRA Facility Assessment, PR/VSI Report, Carswell Air Force Base, Fort Worth, Texas, March 1989.

Naval Air Station Fort Worth Phase 2 RFI OWS Work Plan Revision: 0 October 1999 Page 21 of 21

Law Environmental, Inc., 1995, Installation Restoration Program, Naval Air Station Fort Worth Joint Reserve Base, Final Oil/Water Separator Assessment Report, November 1995.

TABLES

Table 1

Oil/Water Separator RFI Locations OWS Phase 2 RFI Work Plan NAS Fort Worth, Texas Project No. 768579

Building Number	AOC/ SWMU No.	Previous Soil Investigation	Туре	Capacity (gallons)	Year of Installation	Outlet
1015	SWMU 47	LAW and IT	Α	N/D	1967	Sanitary Sewer
1027	SWMU 44	LAW and IT	Α	N/D	N/D	Sanitary Sewer
1060	AOC 11	LAW and IT	Α	750	1985	Sanitary Sewer
1064	AOC 10	LAW and IT	Α	18,000	1988	Sanitary Sewer
1101	N/D	IT	В	4,000	N/D	Sanitary Sewer
1145	AOC 13	LAW and IT	A	1,500	1982	Sanitary Sewer
1190	SWMU 52	LAW and IT	Α	2,000	NA	Sanitary Sewer
1191	SWMU 37	LAW and IT	Α	N/D	1982	Sanitary Sewer
1194	SWMU 35	LAW and IT	Α	N/D	N/D	Sanitary Sewer
1194	N/D	IT	В	N/D	N/D	Sanitary Sewer
1320	N/D	iT	В	400	N/D	Sanitary Sewer
1414	SWMU 41	LAW and IT	Α	1,000	N/D	Sanitary Sewer
1423	N/D	IT	Α	2,700	N/D	Sanitary Sewer
1602	N/D	т	В	18,524	N/D	Sanitary Sewer
1628	SWMU 7	ΙΤ	Α	5,113	1980	Sanitary Sewer
1643	SWMU 40	ΙΤ	Α	20,000	1982	Sanitary Sewer
1655	N/D	it it	A	N/D	N/D	Sanitary Sewer
1656	N/D	IT	Α	18,524	1989	Sanitary Sewer
3358	N/D	ΙŤ	В	N/D	N/D	Sanitary Sewer
4146	N/D	ΙT	Α	N/D	1983	Sanitary Sewer
4160	N/D	ΙŤ	В	N/D	1984	Sanitary Sewer
4210	AOC 12	IT	Α	N/D	N/D	Sanitary Sewer

Notes:

A - Oil/water separator

B - Grit/oil interceptor

N/D - Not determined

Table 2

Oil/Water Separator Phase 2 RFI Status Table With Recommended TNRCC Risk Reduction Program Action OWS Phase 2 RFI Work Plan NAS Fort Worth, Texas Project No. 768579

(Page 1 of 8)

						_								_						_					—
Recommendations	Run SPLP Method 1312 test	for surface and subsurface soils		Prepare CMS Study if neccessary	Submit Standard II Closure	w/Deed Restriction	Run SPLP Method 1312 test	for surface and subsurface soils			Prepare CMS Study if neccessary	Submit Standard II Closure	w/Deed Restriction						Run SPLP Method 1312 test	for surface and subsurface soils		Prepare CMS Study if neccessary	Submit Standard II Closure	w/Deed Restriction	
TNRCC RRS ⁴	II pass SPLP			II pass SPLP			II pass SPLP						il pass SPLP						=		Il pass SPLP				
Units	mg/kg	Бу/бш	mg/kg	mg/kg	mg/kg	mg/kg	mg/kg	mg/kg	mg/kg	mg/kg	mg/kg		mg/kg	mg/kg	mg/kg	mg/kg	mg/kg	рgЛ	hg/L	hg∕L	mg/kg	шд/ка	т9/кд	mg/kg	mg/kg
Max Result	10	2.3	280000	F	1,2	25	10	6.1	28	58	069		14	1.5	30	909	2900	0.36	0.37	444	9.6	0.74	290000	30	6400
Constituent	ARSENIC	CADMIUM	CALCIUM	ARSENIC	CADMIUM	COPPER	ARSENIC	CADMIUM	COPPER	LEAD	ZINC		ARSENIC	CADMIUM	COPPER	MANGANESE	MAGNESIUM	BERYLLIUM	BERYLLIUM	IRON	ARSENIC	CADMIUM	CALCIUM	COPPER	MAGNESIUM
Media Affected	SURFACE	SOIL		SUBSURFACE	SOIL		SURFACE	SOIL					SUBSURFACE	SOIL				Groundwater	Groundwater		SURFACE	SOIL			
Sample Locations	101501	101502		101501	101502	101503	102701						102701	102702	102702	102704		WITCTA037	WITCTA022		106003				
SWMU/ AOC	SWMU	47					SWMU	4											AOC	-					
OWS Blda.	1015						1027	-											1060						

Table 2

Oil/Water Separator Phase 2 RFI Status Table With Recommended TNRCC Risk Reduction Program Action OWS Phase 2 RFI Work Plan NAS Fort Worth, Texas Project No. 768579

(Page 2 of 8)

SMO	SWMU/	Sample	Media		Max		TNRCC	
Bida	ADC	Locations	Affected	Constituent	Result	Units	RRS4	Recommendations
3					A. Carrier de la			
1060	AOC	106001	SUBSURFACE	ARSENIC	12	mg/kg	II pass SPLP	
(Continued)	Ξ	106003	SOIL	CADMIUM	2.2	mg/kg		
•		106004		COPPER	30	mg/kg		
				IRON	16000	mg/kg		
				MAGNESIUM	3400	mg/kg		
				MANGANESE	1100	mg/kg	•	
1084	AOC	WITCTA035	Groundwater	IRON	1070	hg/t	=	Run SPLP Method 1312 test
	9			MANGANESE	588	tug/L		for surface and subsurface solds
		106402SBA	SURFACE	CADMIUM	1.6	mg/kg	If pass SPLP	Prepare CMS Study if neccessary
			SOIL					Submit Standard II Closure
								w/Deed Restriction
		106401	SUBSURFACE	ARSENIC	16	mg/kg	II pass SPLP	
		106402	SOIL	CADMIUM	4.0	mg/kg		
				COPPER	87	mg/kg		
				MAGNESIUM	2600	₽ %		
				MANGANESE	470	mg/kg		
				ZINC	4	mg/kg		
1101	Q	SB110101	SURFACE	BERYLLIUM	1,1	mg/kg	II pass SPLP	Run SPLP Method 1312 test
			SOIL	CADMIUM	0.69	mg/kg		for surface and subsurface soils
				IRON	18400	mg/kg		
				'				Prepare CMS Study if neccessary
		\$8110101	SUBSURFACE	ARSENIC	11.3	mg/kg	II pass SPLP	Submit Standard II Closure
			SOIL	CADMIUM	0.7	mg/kg		w/Deed Restriction
				IRON	15600	mg/kg		
				VANADIUM	49.5	mg/kg		
	Q	WITCTA019	Groundwater	BERYLLIUM	0.51	J/gr		
				MANGANESE	315	ng/L		

Table 2

Oil/Water Separator Phase 2 RFI Status Table With Recommended TNRCC Risk Reduction Program Action OWS Phase 2 RFI Work Plan NAS Fort Worth, Texas Project No. 768579

(Page 3 of 8)

_										_							_									ョ
	Recommendations	Continue LNAPL Removal	Continue Groundwater Monitoring	Test for Metals Leaching	w/SPLP Method 1312 test	for surface and subsurface soils		Prepare CMS Study	Submit Standard It Closure	w/Deed Restriction																
TNRCC	RRS*	=												II pass SPLP						C 4000	17 in 8884 II					
	Units			rg/L	₽Ø√.	μgΛ.	µg/L	µg√L	Hg/L	정	FIQT.	HQ/L	Hg/L	mg/kg	mg/kg	mg/kg	mg/kg	mg/kg	mg/kg	90	R C	mg/kg	mg/kg	mg/kg	mg/kg	mg/kg
Max	Result			9,5	3.7	0.39	1.6	3.3	3.4	3.9	3.7	3.3	2.1	17	310000	2.3	0.69	159	0.0073	[t is	0.64	3.2	0.022	0.0059	0.18
	Constituent	LNAPL		1,1-DICHLOROETHANE	1,2,4-TRIMETHYLBENZENE	1,2-DICHLOROBENZENE	1,3,5-TRIMETHYLBENZENE	BENZENE	ETHYLBENZENE	O-XYLENE	TOLUENE	NAPHTHALENE	VINYL CHLORIDE	ARSENIC	CALCIUM	CADMIUM	ANTIMONY	LEAD	TOLUENE		ANGEMIC	ANTIMONY	CADMIUM	N-BUTYLBENZENE	N-PROPYLBENZENE	NAPHTHALENE
Media	Affected	Groundwater		Groundwater										SURFACE	SOIL	ı					当のないとうならら	SOIL				
Sample	Locations	WITCTA036		WITCTA041										114503	114504	SB114507				,626.00	2	114502	114503	114504		
SWMU/	AOC	AOC	13																							
OWS	Bldg.	1145																	-							

Table 2

Oil/Water Separator Phase 2 RFI Status Table With Recommended TNRCC Risk Reduction Program Action OWS Phase 2 RFI Work Plan NAS Fort Worth, Texas Project No. 768579

(Page 4 of 8)

OWS	SWMU/	Sample	Media		Max		TNRCC	
Bldg.	AOC	Locations	Affected	Constituent	Result	Units	RRS ⁴	Recommendations
130	SWMU	WITCTA032	Groundwater	ARSENIC	35.8	rg.	=	Run SPLP Method 1312 test
	25			IRON	4880	ъgч		for surface soils
				MANGANESE	663	µg∕l.		
								Prepare CMS Study if neccassary
		11901	SURFACE	ARSENIC	7.6	тдука	II pass SPLP	Submit Standard If Closure
		11902	SOIL	CADMIUM	3.6	mg/kg		w/Deed Restriction
1070		11903						
1191	SWMU	WITCTA031	Groundwater	ARSENIC	51.7	μgγ	=	Additional Contaminant Delineation
	35			BARIUM	1490	рgվ		Sample west wall OWS
				IRON	5350	hg/L		surface soils for VOCs & metals
				MANGANESE	1720	μg/L		SPLP Method 1312 test
								for surface and subsurface soils
		119103	SURFACE	SILVER	2	mg/kg	II pass SPLP	Resample WITCTA031
		119104	SOIL	CALCIUM	404000	mg/kg		
								Prepare CMS Study if neccessary
		119101	SUBSURFACE	ARSENIC	14	тд/ка	II pass SPLP	Submit Standard II Closure
		119102	SOIL	CALCIUM	370000	талка		w/Deed Restriction
		119103		CADMIUM	2.7	mg/kg		
		119104		COPPER	16	тд/кд		
1194	SWMU	BGSMW01	Groundwater	IRON	2310	η⁄βη	=	Additional Contaminant Delineation
	. 35			MANGANESE	528	hg/L		SPLP Method 1312 test
				MERCURY	0.11	ъgч		for surface and subsurface soils
Investigated								
by HGL		WITCTA027	Groundwater	IRON	2870	된		Prepare CMS Study if neccessary
				SILVER	4 .6	μgγ		Submit Standard II Closure
								w/Deed Restriction

Table 2

Oil/Water Separator Phase 2 RFI Status Table With Recommended TNRCC Risk Reduction Program Action OWS Phase 2 RFI Work Plan NAS Fort Worth, Texas Project No. 768579

(Page 5 of 8)

						_			_	_		_									_	_				—
	Recommendations						No Further Action	Submit Standard II Closure	w/Deed Restriction	Run SPLP Method 1312 test	for surface and subsurface soils			Prepare CMS Study if needed	Submit Standard II Closure	w/Deed Restriction										
TNRCC	RRS*	II pass SPLP		II pass SPLP						=		II pass SPLP						II pass SPLP								
	Units	mg/kg	mg∕kg	тдука	mg/kg	mg/kg	mg/kg			hg∕t.		mg/kg	mg/kg	mg/kg	mg/kg	mg/kg	mg/kg	mg/kg	mg/kg	mg/kg	mg/kg	mg/kg	mg/kg	mg/kg	mg/kg	
Max	Result	2.4	24	5.7	2.7	370	3.8			249		8.7	2.2	16	16000	51	430	11	150	1.6	7.7	18	51	3100	200	
	Constituent	CADMIUM	COPPER	ARSENIC	CADMIUM	MANGANESE	SILVER			IRON		ARSENIC	CADMIUM	COBALT	IRON	LEAD	MANGANESE	ARSENIC	BARIUM	CADMIUM	COBALT	COPPER	LEAD	MAGNESIUM	MANGANESE	
Media	Affected	SURFACE	SOIL	SUBSURFACE	SOIL		SUBSURFACE	SOIL		Groundwater		SURFACE	SOIL					SUBSURFACE	SOIL							
Sample	Locations	119402		119401	119402	119403	SB132002			WITCTA016		DIP1703						DP1701	DP1702	DP1703						
SWMU/	AOC			SWMU	35		Q			SWMU	4															
SMO	Bldg.	1194	(Continued)	· ·			1320			1414									÷							

Table 2

With Recommended TNRCC Risk Reduction Program Action OWS Phase 2 RFI Work Plan NAS Fort Worth, Texas Project No. 768579 Oil/Water Separator Phase 2 RFI Status Table

(Page 6 of 8)

		_	_																							٦
TNRCC	Recommendations	No Further Action	Submit Standard II Closure	w/Deed Restriction			Run SPLP Method 1312 test	for surface and subsurface soils		Submit Standard II Closure	w/Deed Restriction										Run SPLP Method 1312 test	for subsurface soits		Submit Standard II Closure	w/Deed Restriction	
TNRCC	RRS*	=		<u>-</u>		=		"			II pass SPLP					II pass SPLP							II pasa SPLP			=
	Units	hg⁄L		mg/kg		mg/kg	T/Grt	hg/L	l/bri		mg/kg	mg/kg	mg/kg	mg/kg	-] mg/kg	mg/kg	mg/kg	mg/kg	mg/kg	0.76		377	0.47		9.2
Max	Result	2720		0.53		0.39	24.4	799	630		46.5	.10	1.6	0.42		9.1	0.67	8.5	18300	0.51	8.06		2.38	8.33		56.05
	Constituent	IRON		SILVER		SILVER	ARSENIC	IRON	MANGANESE		CHROMIUM	LEAD	MOLYBDENUM	SILVER		ARSENIC	BERYLLIUM	COBALT	IRON	SILVER	SILVER		MANGANESE	SILVER		LEAD
Media	Affected	Groundwater		SURFACE	SOIL	SUBSURFACE SOIL	Groundwater				SURFACE	SOIL				SUBSURFACE	SOIL				SURFACE		SUBSURFACE			SURFACE
Sample	Locations	WITCTA014		SB142301	SB142302	SB142302	WITCTA011				SB160201	SB160202				SB160201	SB160202				MS1418		MS1422			MS1368
SWMU/	AOC	2					₽														SWMU					
SMO	Bldg.	1423					1602											-			1628		Investigated	by HGL	•	

Table 2

Oil/Water Separator Phase 2 RFI Status Table With Recommended TNRCC Risk Reduction Program Action OWS Phase 2 RFI Work Plan NAS Fort Worth, Texas Project No. 768579

(Page 7 of 8)

_	—Ir	_				- ···•					_			_		ī	_				*******					_			\neg
	Recommendations		Run SPLP Method 1312 test	for surface soils		Thirty Office Constitution	righted cites along	Submit Standard II Closure	w/Deed Restriction			No Further Action	Submit Standard If Closure	w/Deed Restriction			No Further Action	Submit Standard II Closure	w/Deed Restriction	Run SPLP Method 1312 test	for surface soils	Prepare CMS Study if needed	Submit Standard II Closure	w/Deed Restriction	Run SPLP Method 1312 test	for surface soils		Submit Standard II Closure	w/Deed Restriction
TNRCC	RRS*						LILO SSEC I			=		=			=		¥			II pass SPLP					II pass SPLP				:
	Units		√gr	Fg.	hg/L	1	D S O	бу/бш		mg/kg	3 315.	hg/L	hg/t	7/6ri	mg/kg	mg/kg	mg/kg	mg/kg	mg/kg	mg/kg	mg/kg	mg/kg			mg/kg	тд/ка	шд/кд	тд/кд	
Мах	Result		28.2	1740	1660			81.8	İ	17000	-	1470	776	177000	136	2210	302000	3320	1.8	7.8	91.6	91.5			234000	42	1.6	0.62	
· · · · · · · · · · · · · · · · · · ·	Constituent		ARSENIC	IRON	MANGANESE	:	CADMIUM	LEAD		IRON		IRON	MANGANESE	SODIUM	BARIUM	MANGANESE	CALCIUM	MAGNESIUM	SILVER	ARSENIC	LEAD	ZINC			CALCIUM	LEAD	MOLYBDENUM	SILVER	
Media	Affected		Groundwater				SURFACE	SOIL		SUBSURFACE	SOIL	Groundwater			SUBSURFACE	SOIL	SURFACE	SOIL		SURFACE	SOIL				SURFACE	SOIL			
Sample	Locations		WITCTA006				SB164301	SB164302		SB164301		WITCTA004			SB165502		SB165601			SB335801					SB414601	SB414602	SB414603		
SWMU/			SWMU	40			-					2					Q			Ş					2				
SMO	Bldg.		1643		Investigated	by HGL						1655					1656			3358					4146			_	

Table 2

With Recommended TNRCC Risk Reduction Program Action Oil/Water Separator Phase 2 RFI Status Table **OWS Phase 2 RFI Work Plan** NAS Fort Worth, Texas Project No. 768579

(Page 8 of 8)

/ Sample Media Max TNRCC Locations Affected Constituent Result Units RRS ⁴ Recommendations	SB4604 SUBSURFACE CALCIUM 325000 mg/kg II	SOIL MAGNESIUM 2730 mg/kg	MANGANESE 859 mg/kg	SILVER 0.42 mg/kg	SB416001 SURFACE SILVER 0.53 mg/kg II No Further Action	Soll Submit Standard II Closure	w/Deed Restriction	VAITCTA020 Groundwater BERYLLIUM 0.51 µg/L it Additional Contaminant Delineation		for VOCs & metals	Run SPLP Method 1312 test	421001SBF SUBSURFACE ARSENIC 19 mg/kg if pass SPLP for subsurface soils	CADMIUM 1.8 mg/kg	COBALT 12 mg/kg Submit Standard II Closure	COPPER 52 mg/kg w/Deed Restriction	IRON 17000 mg/kg	LEAD 36 mg/kg	MANGANESE 660 mg/kg	NICKEL 16 mg/kg	VANADIUM 38 mg/kg	ZINC 32 mg/kg
Media Affected	SUBSURFACE		~	,	SURFACE	SOIL		Groundwater				SUBSURFACE)	J	J	-	J	•	-		
OWS SWMU/ Bldg. AOC	4146	(Continued)			4160 ND			4210 AOC	12										-		

Notes:

- 1 UTLs derived from Draft Basewide Background Study, Jacobs Engineering, January 1997. No background concentration available for organic compounds.
 - 3 TNRCC Risk Reduction Standard Media-Specific Concentration (MSC) Industrial Setting.
 - 4 Proposed TNRCC Risk Reduction Program Standard.

It pass SPLP - Standard It closure can be achieved if soils pass SPLP Method 1312 test.

Boxed cell represents constituent concentration greater than both the UTL and the MSC.

Organic compounds exceed the method PQL.

KNW624KOsppsamp/3/10/14/99/1:49 PM

Table 3

Analytical Soil Boring Samples OWS Phase 2 RFI Work Plan NAS Fort Worth, Texas Project No. 768579

Analysis	sis				VOA by SW8260	SVOA by SW8270	TAL Metals by SW6010/7000	PesUPCB by SW8080	SPLP VOA by SW1312/SW 8260	SPLP VOA SPLP SVOA by by SW1312/SW8 8260 270	SPLP Metals by SW1312/SW6010B (Trace)
		No. of field be taked	No. of field samples to be taken at each location excluding QC	Rationale: Confirm/ Delineate	None, 4°C	None, < 4°C	None, 4°C	None, 4°C	None, 4°C	None, 4°C	
Location	 Map Location	samples. No Surface	samples. Please see Note 1 Surface Subsurface		14 Days	7 Days preext. 40 days postext	180 Days	14 Days preext./ 40 days postext.		None	
SB101503	BLDG1015	-	-	Delineate Law SB 101502			×				×
SB101504	BLDG1015	-	-	Confirm Law SB 101501			×				
SB102703	BLDG1027	-	1	Delineate Law SB 102701			×				×
SB102702	BLDG1027	0	+	Confirm Law SB 102702			×				
SB106003	BLDG1050	-	-	Delineate Law SB 106003			×				×
SB106004	BLDG1060	0	-	Delineate Law SB 106001			×				
SB106403	BLDG1064	-	-	Delineate Law SB 106402			×				×
SB106404	BLDG1064	0	1	Delineate Law SB 106401			×				
SB110103	BLDG1101	-	1	Confirm IT SB110101			×				× ;
SB114510	BLDG1145	-	1	Delineate IT SB114507			×				×
SB119003	BLDG1191	-	0	Delineate IT SB119103							
SB119105	BLDG1191	0	1	Delineate Law SB 119101&-03			×				×
SB141403	BLDG1414	0	-	Delineate Law SB 141401			×				>
SB141404	BLDG1414	-	-	Delineate Law SB 141403			×				<
SB160203	BLDG1602	-	1	Confirm IT SB160201			×				×
SB335808	BLDG3358	-	0	Confirm IT SB335801			×				;
SB414601	BLDG4146	-	0	Confirm IT SB 414602			×				×
SB421003	BLDG4210	0	1	Confirm Law 421001			×				Y
SB421004	BLDG4210	0	1	Delineate Law 421001			×				
	Totals	12	16								

Note 1 - QC samples to be taken: MS/MSD - 5% of total field samples, 1 set per SDG or 1 set per 20 samples. Dup. - 10% of total field samples. Mat. Blk - 1 per water soutce/matrix. Total blk - 1 per VOA cooler. Equip. Rinse - 1 per day.

Table 4

Analytical Groundwater Samples OWS Phase 2 RFI Work Plan NAS Fort Worth, Texas Project No. 768579

No. of field Rationale/DQO Rationale/DQO (Dissolved) Rationale/DQO TAT VOC samples screening rapid 3 * 40 ml glass vials 1 Liter glass 500 ml glass 500 ml glass to be collected at each location 14 Days 7 Days preext.// 40 days postext. 180 Days Confirm/Resample -Be only X - Be samples. X Confirm/Resample - Be only X - Be Confirm/Resample - Be only X - Be X X - Be Confirm/Resample - Be only X - Be X X - Be Confirm/Resample - VOC Only X - As, Ba, Mn Only X -		The state of the s			TAL Metals by		Pie E
No. of field screening rapid screening rapid account of field and be collected at each location and least vials vials and least vials and least vials and least vials and l			VOA by SW8260	SVOA by SW8270	SW6010/7000	Rationale/DQO	Parameters
No. of field TVOC samples TVOC samples be collected at samples. TVOC samples. TVOC samples Samples. And mi glass vials T Days preext. T Days preext. T Days postext. T Days postext. T Days postext. X - Be Confirm/Resample - Be only X - Be Confirm/Resample - WCC Only X - Be Confirm/Resample - WCC Only X - Be Confirm/Resample - WCC Only X - As, Ba, Mn Confirm/Resample - WCC Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn O				•	(Dissolved)		(See Table 3-6)
T VOC samples be collected at samples. samples. x Lee Confirm/Resample - Be only X - Be Confirm/Resample - Be only X - Be Confirm/Resample - VOC Only X - Be Confirm/Resample - VOC Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate -	No. of field samples to be taken at each	No. of field screening rapid	HCL. < 4°C	None, < 4°C	HNO3, < 4°C		
sach location 14 Days 7 Days preext./ 180 Days samples. A days postext. X - Be Confirm/Resample - Be only x X - Be Confirm/Resample - Be only x X - Be Confirm/Resample - Be only x X - Be Confirm/Resample - WCC Only x X - As, Ba, Mn Confirm/Resample - WCC Only x X - As, Ba, Mn Confirm/Resample - WCC Only x X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn X - As, Ba, Mn X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn X - As, Ba, Mn X - As, Ba, Mn Confirm/Resample - Be only	ocation excluding QC	TAT VOC samples	3 * 40 ml glass vials	1 Liter glass	500 ml glass		
40 days postext. X - Be Confirm/Resample - Be only X - Be Confirm/Resample - Be only X Se Confirm/Resample - Be only X Confirm/Resample - WCC Only X Confirm/Resample - VCC Only X Confirm/Resample - VCC Only X X - As, Ba, Mn X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Confirm/Resample - As only X - As, Ba Confirm/Resample - As only	samples. Please see Note 1	each location	14 Days	7 Days preext./	180 Days		
X - Be Confirm/Resample - Be only X - Be Confirm/Resample - Be only X Confirm/Resample - Be only X Confirm/Resample - WCC Only X Confirm/Resample - WCC Only X Confirm/Resample - WCC Only X X - As, Ba, Mn X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba Confirm/Resample - As only X - As Confirm/Resample - As only	Delinate	excideing 40		40 days postext.			
X - Be Confirm/Resample - Be only X - Be Confirm/Resample - Be only Confirm/Resample - WCC Only Confirm/Resample - WCC Only X - As, Ba, Mn Confirm/Resample - WCC Only X - As, Ba, Mn Confirm/Resample - WCC Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Confirm/Resample - As only X - As Confirm/Resample - As only	-				X - Be	Confirm/Resample -Be only	×
X - Be Confirm/Resample - Be only Confirm/Resample - VOC Only Confirm/Resample - VOC Only X - As, Ba, Mn Confirm/Resample - VOC Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Confirm/Resample - As only X - As Confirm/Resample - As only X - Be Confirm/Resample - Be only					X-Be	Confirm/Resample -Be only	×
Confirm/Resample - VOC Only Confirm/Resample - VOC Only X - As, Ba, Mn Confirm/Resample - VOC Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Confirm/Resample - As only X - As Confirm/Resample - As only X - Be Confirm/Resample - Be only					X · Be	Confirm/Resample -Be only	×
Confirm/Resample - VOC Only X - As, Ba, Mn Confirm/Resample - VOC Only X - As, Ba, Mn Confirm/Resample - As, Ba, Mn X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Confirm/Resample - As only X - As Confirm/Resample - As only X - Be Confirm/Resample - Be only			×			Confirm/Resample - VOC Only	×
X - As, Ba, Mn Confirm/Resample - VOC Only X - As, Ba, Mn Confirm/Resample - As, Ba, Mn X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Delineate - As, Ba, Mn Only X - As, Ba, Mn Confirm/Resample - As only X - As Confirm/Resample - As only X - Be Confirm/Resample - Be only			×			Confirm/Resample - VOC Only	×
Confirm/Resample - As, Ba, Mn Delineate - As, Ba, Mn Only Confirm/Resample - As only Confirm/Resample - As only			×			Confirm/Resample - VOC Only	×
Delineate - As, Ba, Mn Only Confirm/Resample - As only Confirm/Resample - Be only					X - As, Ba, Mn	Confirm/Resample - As, Ba, Mn	×
Delineate - As, Ba, Mn Only Delineate - As, Ba, Mn Only Delineate - As, Ba, Mn Only Confirm/Resample - As only Confirm/Resample - Be only	-				X - As, Ba, Mn	Delineate - As, Ba, Mn Only	×
Delineate - As, Ba, Mn Only Delineate - As, Ba, Mn Only Confirm/Resample - As only Confirm/Resample - Be only	-				X - As, Ba, Mn	Delineate - As, Ba, Mn Only	×
Delineate - As, Ba, Mn Only Confirm/Resample - As only Confirm/Resample - Be only	-				X - As, Ba, Mn	Delineate - As, Ba, Mn Only	×
Confirm/Resample -As only Confirm/Resample -Be only	-				X - As, Ba, Mn	Delineate - As, Ba, Mn Only	×
Confirm/Resample -Be only					X - As	Confirm/Resample -As only	×
					X - Be	Confirm/Resample -Be only	×
	4						

Note 1 - QC samples to be taken: MS/MSD - 5% of total field samples, 1 set per SDG or 1 set per 20 samples. Dup. - 10% of total field samples. Mat. Bik - 1 per water soutce/matrix. Total bik - 1 per VOA cooler. Equip. Rinse - 1 per day.

Table 5

Summary Table of all Soil Boring and Groundwater Samples
OWS Phase 2 RFI Work Plan
NAS Fort Worth, Texas
Project No. 768579


i d	Analytical Method	Matrix	Number of	Field Duplicate	Matrix Spike 5%	Matrix Spike Duplicate 5%	Material Blank 1 per source/ matrix	Equip. Rinsate 1 per Day	Trip Blank 1 per VOA cooler	Total No. of Samples	Combined Total No. of Water/Soil Samples
Volatiles	SW8260	Soil	0	0	0	0	0	0	0	0	
		Water	8	1	1	+	0	-	-	9	
		Combined									9
Semivolatiles	SW8270	Soil	0	0	0	0	0	0	0	0	
		Water	0	0	0	0	0	0	0	0	
		Combined									0
Z Z Z	SW6010b Trace/	Soll	45	5	2	2	6	ເດ	0	55	
	+	Water	20	2	+-	1	1	2	0	24	
		Combined									79
d ids	EPA Method 1312	Soil	4	-	-		0	0	0	15	
	SW60101b Trace	Water	0	0	0	0	0	0	O,	0	
	7300	Combined									15
Field		Č	C	c	c	C		<u> </u>		G	
Parameters	Sed lable o	Water	2 2	, 0				0	0	13	
		Combined									13

Table 6


Groundwater Field Sampling Test and Method Table OWS Phase 2 RFI Work Plan NAS Fort Worth, Texas Project No. 768579

Field Analysis	Method
Dissolved Oxygen	E360.1
Redox Potential	Martin Marietta Energy Systems, Inc. Environmental Surveillance Procedures, ESP-307-5
pH	SW9040
Total Volatiles	PID Organic Vapor Monitor
Conductivity	sw9050
Temperature	E170.1
Turbidity	E180.1

FIGURES



DMC: NOT: / \2882\368148



DWG: NÖ:::/Y68579es:150

IMAM .M : ROTAITIN

NATE LAST REV :

DBAFT, CHCK, BY: R, KNICHT

IMAM .M : ROTAITINI

DMC1 NO1111 / 1288 2362121

14:12:80

ENGE, CHCK, BY: M. MAKI

DBAFT, CHCK, BY: R, KNIGHT

PROJ. MGR.:W.CARTER

IMAM .M : ROTAITINI

PROJ. NO.:768579

DMC: NO:::/\kg8579es.152

TRAWN BY:

DATE LAST REV:


Sdf.zae%Z88X/ngizab/bboo/:o

21 OCT 1999

11:05:04

TUOTS J :YE WWARD

STARTING DATE: 10/7/97



965,000

Ġ,

T. \$1001

76/2/01 :3TAG DNITRATZ

:Y8 NWARO

DATE LAST REV.:

YB NWARO

\$1 OC1 1888

10:27:42

ggl:sa6/3887/npisab/bbba/:p

965,100

တ်

ENCK, CHCK, BY:

DRAFT, CHCK, BY: R. KNICHT

M. MAKI

E 2,299,200

PROJ. NO.:768579

PROJ. MGR.: W.CARTER

MAM. M. MAKI

INAM .M : ROTAITIN

DMC: NOT: / \2882\364126

DRAWN BY:

DATE LAST REV.:

ENGB' CHCK' BA:

DRAFT, CHCK, BY: R, KNIGHT

IMAM .M

PROJ. MGR.:W.CARTER

INITIATOR: M. MAKI

PROJ. NO.:768579

DWG, NO.1., 768579es, 157

DRAWN BY:

L. STOUT

STARTING DATE: 10/8/97

21 OCT 1999

97:51:11

Cdf.z9eVd8dV/ngis9b/bboo/-o

6,966,900

ENCB' CHCK' BA:

DRAFT, CHCK, BY: R. KNIGHT

M. MAKI

DRAWN BY:

LV3R TZAJ 3TAQ

8čf.zee7č8857/ngizeb/bboo/:o

DRAWN BY:

L. STOUT

STARTING DATE: 10/8/97

21 OCT 1999

St:60:11

E 5,297,200


678851: ON .LORG


891.296788877.20U.3WQ


6,967,000

PROJ. MGR.:W.CARTER

INITIATOR: M. MAKI







TELETING DATE: 10/8/97

:.V38:12A1 3TA0

DRAFT, CHCK, BY: R, KNICHT

INTIATOR: M. MAKI

DMC: NO:::/\\2882\368161

13:25:06

z

ENGB' CHCK: 8A:

DRAFT, CHCK, BY: R, KNIGHT

M. MAKI

PROJ. MCR.: W.CARTER

INITIATOR: M. MAKI

PROJ. NO.:768579

DWG: NO.:... 768579es.162

DRAWN BY:

DATE LAST REV:

в, киіснт

STARTING DATE: 11/6/97

:YE NWARO

\$1 OCT 1999

12:56:45

Sal.zee\7883\/ngizeb/bboo/;o

Calleae778837/ngiseb/bboo/:o

DRAWN BY: R. KNICHT

STARTING DATE: 11/7/97

:Y8 NWARO

EVER LAST REVE

21 OC1 1888

12:53:11

z

PROJ. MGR.:W.CARTER


INAM .M : SOTAITINI

PROJ. NO.:768579

DWG, NO.::\768579&\$163

ENGB' CHCK' BA: M' MYKI

DRAFT, CHCK, BY: R, KNICHT



\$1 OCT 1999 DRAFT CHCK, BY: R. KNICHT

MAM .M :ROTAITINI

DMC: NO: "7488218416

CV3R T2A1 3TAG

ELVER TEAU STAC

IMAM M :ROTAITINI

DMC: NO.11.776857965.165

DBAFT, CHCK, BY: R. KNICHT

21 OCT 1999

14:32:54

SE NWA 90

8' KNICHT

STARTING DATE: 10/17/97

of/codd/design/788579es.756

z

PROJ. NO.:768579

PROJ. MCR.: W. CARTER

IMAM .M :ROTAITINI

THENCH CHCK. BY:

DATE LAST REV. 21 OCT 1999 DRAFT. CHCK. BY: R. KNICHT

M. MAKI

DRAWL BY:

EV38 TZAJ BTAO

DMC: NOT: / \2882\36216\

INAM .M : ROTAITIN

DBAFT, CHCK, BY: R, KNIGHT

STARTING DATE: 10/8/97

6.1 Conclusions

6.2 Recommendations


Tables

Figures

Appendix A - Oil/Water Separator Assessment Reports


Figure 24

OWS Phase 2 RFI Addendum Report Outline NAS Fort Worth, Texas



	•		
	.		
	4th Quarter		
			\$
			 Rolled Up Progress
	3rd Quarter		Rolled t
	1 1		
lon			
restigat ∧FB	2nd Quarter		sk estone
rigure 23 'hase 2 Investi Carswell AFB	2nd		Summary Rolled Up Task Rolled Up Milestone
rigure 25 OWS Phase 2 Investigation Carswell AFB	1st Quarter		Su Ro
	4th Quarter	DO DO	Task Progress Milestone
	3rd Ouarter	des for the second of the seco	Project: OWS Carswell AFB Date: 8/10/99

Figure 26. Project Organization - NAS Fort Worth (Project No. 768579)



FINAL PAGE

ADMINISTRATIVE RECORD

FINAL PAGE